



PremiumLift

Deluxe Floor Bed

Foldable Side Rails

Assembly Instructions



1. Components

2. Position and screw brackets on side of the bed frame. Place bracket with pin on the head end



3. Insert side rail using bolt and washers (1x stainless steel washer + 1x small white plastic washer for bolt and 1x large plastic washer between bracket and rail). Two plastic washers will remain unused after assembly as spare parts.

4. Use lock nut and stainless steel washer to secure the rail to the bed frame.