
## Premium Lift



**QR Code** 

## **REMOTE GUIDE**



## **CAUTIONS**

Scan QR Code, download and read complete User Manual prior to using Deluxe Floor Bed

## HOW TO LOCK CASTORS AT LOWEST POSITION?

- 1. Press Remote Control Castor button until reaching minimum floor position.
- 2. Press Lift button for approximately 2 seconds or until the bed is standing on four legs.
- 3. Deluxe Floor Bed will now be central locked at the lowest position



www.premiumlift.com.au